

Loop/PSC Tester

KEW 4118A - Kyoritsu LOOP/PFC/PSC Testers

Rating: Not Rated Yet
 2-3 Days
 ★★★★★

[Ask a question about this product](#)

Manufacturer [KYORITSU](#)

Description

- Custom microprocessor controlled for highest accuracy and reliability.
- 3 LEDs for checking correct wiring status.
- 15mA LOOP measurement:
 LOOP impedance 2000? range measurement is carried out with low test current (15mA).
 The current will not cause tripping out involved RCD even the one with the lowest nominal differential current (30mA).
- Direct reading of Prospective Short Circuit Current (PSC).
- Safe voltage measurement function.
- Large custom digital display readout on all models.
- Measure low loop resistances(resolution of 0.01?)
- Automatic lock-out if test resistor overheats.
- Large custom digital display readout .
- Visual indication of reversed phase and neutral wiring at socket.
- Designed to IP54 Rating
- Complies with IEC 61557

Loop Impedance Ranges	20/200/2000?
Loop Impedance Accuracy	±2%rdg±4dgt
AC Test Current	20? 25A 200? 2.3A 2000? 15mA
AC Test Period	20? (20ms) 200? (40ms) 2000? (280ms)
PSC Ranges	200A (2.3A 40ms) 2000A (25A 20ms) 20kA (25A 20ms)
PSC Ranges Accuracy	Consider accuracy of Loop impedance
Voltage	110V-260V ±2%rdg±4dgt
Operating Voltage	230V+10% -15% (195V - 253V) 50Hz

Loop Tester: Loop/PSC Tester

Safety Standard	IEC 61010-1 CAT III 300V Pollution Degree 2 IEC 61557-1,-3 IEC 61010-2-031
IP Rating	IEC 60529-IP54
Dimensions	167(L) x 185(W) x 89(D)mm