

SDR35

SDR35 - SEAWARD 35kV Discharge Rod

Rating: Not Rated Yet

[Ask a question about this product](#)

Manufacturer: [SEAWARD](#)

Description

This instrument will allow you to conduct the safe damp discharge of the residual charge on the cable / equipment by limiting the discharge current.

Each model features high grade glass fibre tubing and incorporates encapsulated resistor chains.

It is supplied as standard with earthing wire (10 sq.mmx 5mtr), yellow green wire and carry case.

Features

- Safe HV discharge rod for soft damp discharge of cables and / or equipment under test
- Supplied with flexible cable with heavy duty brass clamp for easy earth connection
- Robust single pole device
- No switches
- Suitable for voltages to 35kV
- Supplied with cushion soft carrying case

Technical specification	
Discharge Voltage	35kV AC/DC max
Peak Discharge Current	13.5A for 100ms
Bleeder Resistance	10k ohm
Discharge Capacitance	6 ?F
Leakage Current at 35KV AC	<50 ?A
Discharge Energy	3675J
Cooling	Neutral
Total Size	32mm x 950mm
Weight	2.2 kg (Net)
Safety	IEC 61230, EMC Not Applicable
Temperature	-5°C to 70°C