

OTS80KV and OTS100kV

OTS80kV & OTS100kV - Altern Dielectric Oil Tester / BDV

Rating: Not Rated Yet

[Ask a question about this product](#)

Manufacturer [ALTERN](#)

Description

- Test voltage range of 0?80KV/100KV
- Display by large-screen LCD.
- Automatically complete the withstand voltage test from 1 to 9 times. After the test, the thermal printer will print each breakdown voltage value and average value.
- Power-down preservation. It can save 100 tested results.
- Adopt a single-chip microcomputer to boost the voltage at an even speed. The voltage is accurate at 50HZ, ensuring the whole process easy for control.
- Equipped with over-voltage, over-current and limit protections to ensure the safety of operators.
- Communicate with computer with a standard RS232 interface.