

Rental CT Analyzer - Vanguard EZCT 2000A

Rating: Not Rated Yet

[Ask a question about this product](#)

Manufacturer [Vanguard](#)

Description

Overview

The EZCT-2000A is Vanguard's third-generation microprocessor-based current transformer test set. The EZCT-2000A can perform the current transformer(CT) excitation test, measure the CT winding resistance and CT current-ratio automatically. All of the EZCT-2000A's test leads can be connected to the CT output terminals (X1, X2, X3, X4 and X5), eliminating the need for lead switching during testing. Test voltage output is automatically raised and lowered by the EZCT-2000A without any operator intervention. With up to 2000 Vac excitation test voltage available, the EZCT-2000A can easily perform excitation testson very large CT's

-

- Perform Saturation, Ratio and Polarity Tests
- Perform CT Winding Resistance Test
- Fully Automated
- Test record header information including company, substation name, circuit ID, manufacturer, CT serial number, operator name, and test record-comments
- Plot Multiple Saturation Curves
- Store 140 Records (of 10 Saturation Curves)
- Computer Interface

Contact Us For Details..